



4453 Main Avenue Suite G

Fargo, ND 58102

(701)850-3736

Subject: Scissor Stack Pin and Bushing Re-Lubrication:

This is to remind all owners of Skid-Lifts that periodic maintenance of all pins and bushings located in the scissor stack do require periodic maintenance and re-greasing. Failure to lubricate pins and bushings on a regular basis can result in damage and possible injury if not maintained. Pins do need to be removed in order to re-grease them and you can refer to information on our website under the “Service” tab to find specific instructions for your particular model.

We recommend the following lubrication intervals for the usages below (roughly 150 hours of usage):

- High usage (Used daily) - Every 3 months
- Medium usage (3-4 times a week) - Every 6 months
- Low/ Occasionally usage (1-2 times per week) - Every 12 months

This service can be done by the user if they have experience working on equipment or by a local equipment mechanic. We recommend users use an EP Moly Grease that can handle extreme pressure and shock loads. We’d also like to remind you that snap rings must be discarded and replaced with new ones once they are taken off. Skid-Lift now offers snap ring replacement kits with instructions which are available for all lift models. Pin replacements can also be purchased upon request if needed.

It also is stated within your Skid-Lift owner’s manual that your lift should be inspected by an experienced equipment mechanic every 12 months. This will ensure your safety and longevity of your Skid-lift.

We are hoping this reiterates the importance of maintenance for your Skid-Lift. If you have any other questions, please do not hesitate to call.